



Desk Fan



First Use Safety Recommendation

Please read through this booklet for safe and efficient use of the appliance. We urge you to read the "Important Safeguards" section and also follow all detailed instructions even if you are familiar with a similar appliance.

Keep this guide handy for future reference.


FD1600

IMPORTANT SAFEGUARDS

When using electrical appliances, in order to reduce the risk of fire, electric shock, and/or injury to persons, basic safety precautions should be followed, including the following:

- Read all instructions carefully, even if you are familiar with the appliance.
- To protect against the risk of electric shock, DO NOT IMMERSE the appliance, cord set or plug in water or other liquids.
- To clean, wipe the exterior with a damp cloth.
- Close supervision is necessary when any appliance is used near children. Never leave an appliance unattended when in use.
- Switch off and remove the plug from the power outlet when not in use, before assembling or disassembling parts or during cleaning. Never pull the cord.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions, or is dropped or damaged in any manner. Return the complete appliance to your nearest authorised service facility for examination, electrical repair, mechanical repair or adjustment.
- The use of attachments or accessories not recommended or sold by this appliance manufacturer may result in fire, electric shock or personal injury.
- Do not let the cord hang over the edge of a table, counter, or touch hot surfaces.
- Avoid touching hot surfaces, use handles and knobs.
- Do not operate or place any part of this appliance on or near any hot surfaces (such as gas or electric burner or in a heated oven).
- Do not abuse the cord. Never carry the appliance by the cord or yank it to disconnect it from the outlet; instead, grasp the plug and pull to disconnect.
- When using an extension cord with your appliance, make sure the extension cord is correctly wired and rated for its use.
- This product is intended for household use only.
- Do not attempt to repair the appliance yourself; instead, take it to your Black & Decker-Owned or Authorised Service Centre for repair.
- Always route the cord carefully to avoid a tripping hazard.
- Do not allow children or any person unfamiliar with these instructions use this appliance.

SAVE THESE INSTRUCTIONS



Parts Identification :- (show the fan with all parts marked)

1. Front Guard with outer rim.

2. Guard securing clip

3. Blade Cap

4. Fan Blade

5. Rear Guard Lock Nut

6. Rear Guard

7. Main Unit

8. Base

9. Oscillation control knob

10. Speed control Knob

11. Handle

12. Power cord

Your Desk Fan Features :

1. Three step speed control for comfortable cooling air.

2. Horizontal sweep for large coverage area.


3. Easy Carry away Handle

4. Guard Securing clip for your safety.

5. 16" fan for better air circulation

Intended Use :-

Your Black & Decker fan has been designed for indoor household use only.




Fitting and assembling:-

Assembling of Base :

Remove all the parts from the packaging material and keep them aside. Ensure that you have all the parts as identified in the Part Identification list, else get in touch with your nearest Black & Decker Service agent for assistance.

Make sure your fan is switched off before connecting to or disconnecting from power supply. Ensure that the voltage rating on the base plate corresponds to the mains voltage at your home.

1. Lead the power cord through the opening in the base.
2. Insert the stand into the base by hinging it from the front side and then snapping it on the two snaps on the rear. Ensure that the main unit is well secured in place to the base.
3. Lead the power cord through the recess at the side of the base.



تعريف الأجزاء : (يوضح المروحة مع جميع الأجزاء المحددة)

١. واقى أمامي مع إطار خارجي

٢. مشبك الأمان للواقى

٣. غطاء الشفرة

٤. شفرة المروحة

٥. صمولة قفل للواقى الخلفي

٦. واقى خلفي

٧. الوحدة الرئيسية

٨. القاعدة

٩. مقبض التحكم بطريقة الدوران

١٠. زر التحكم بالسرعة

١١. مقبض

١٢. سلك كهربائي

مزايا مروحة المكتب:

١. تحكم بالسرعة من ثلاث خطوات لهواء بارد منعش.

٢. حركة عمودية لشمول منطقة تبريد أكبر


٣. مقبض حمل سهل الاستخدام

٤. مشبك أمان للواقى لسلامتك

٥. مروحة ١٦ بوصة لتوزيع الهواء على اكمل وجه

الاستخدامات:

تم تصميم مروحة بلاك آند ديكر للاستخدام المنزلي فقط.



التجهيز والتركيب:

تركيب القاعدة:

انزع مواد التغليف عن جميع القطع واحتفظ بها جانباً. تأكد من وجود جميع الأجزاء المذكورة في قائمة تعريف الأجزاء، أو اتصل مع اقرب وكيل خدمات بلاك أند ديكر لتقديم المساعدة. تأكد من إغلاق المروحة قبل توصيلها أو نزعها من مصدر الكهرباء. تأكد من أن الفولطية في صفحة القاعدة متوافقة مع الفولطية الرئيسية في منزلك.

١. مرر السلك الكهربائي عبر الفتحة الموجودة في القاعدة.

٢. ادخل القائم في القاعدة بتعليقها من الجانب الأمامي وثم أغلق المشابك من الخلف. تأكد من أن الوحدة الرئيسية في مكانها الصحيح على القاعدة.

٣. مرر السلك الكهربائي عبر الفجوة في جانب القاعدة.

ضمان شامل لمدة سنتين لأدوات BLACK & DECKER المنزلية

تمنح Black & Decker ضمان شامل مدته سنتين للمنتج اعتباراً من تاريخ الشراء، يسري الضمان على عيوب التصنيع أو عيوب المواد الداخلة في التصنيع. في حالة إصابة المنتج بأي عطل زثناء فترة الضمان، فإن لشركة Black & Decker حرية الاختيار إما إصلاحه أو استبداله بدون أي تكلفة.

لا يغطي الضمان الأعطال الناتجة عن الحوادث، سوء الاستعمال، الإهمال، الاستعمال الخاطئ، أو عدم اتباع النظم المعمل بها ؟اليا. كذلك، لا تنطبق شروطالضمان إذا تمك صيانة أو تصليح المنتج لدي طرف غير معتمد من قبل شركة Black & Decker ، أو عند استخدام قطع غيار بدون الرجوع أو أخذ موافقة الشركة وتسببت هذه القطع في العطل إذا توقف إنتاج أي طراز مع عدم وجود البديل المناسب، فإن لشركة Black & Decker الحرية في إصلاح المنتج أو استبداله بطراز آخر ذو نفس القيمة الشرائية.

إتمام عمالية الشراء

إملاً بطاقة تسجيل الضمان مع التأكد من وجود الختم الأصلي للوكيل المعتمد (وتوضيح تاريخ الشراء) ثم أرفق إيصال الشراء بالبطاقة. الرجاء الاحتفاظ بهما لإبرازهما في حالة المطالبة في المستقبل.

عملية المطالبة

خذ المنتج المعطل مع بطاقة الضمان وإيصال الشراء بنفسك إلى مركز الصيانة المحلي. أو يمكنك إرساله بالبريد. في حالة الإرسال بالبريد أو الشحن: تأكد من تفريغ المنتج من الماء كلياً وقم بتغليفه جيداً في صندوق كرتوني مع إضافة مواد تغليف لملاً الفراغات لتفادي الإصابة بأي ضرر. أفق شرح موجز للمشكلة وتأكد من إعطاء اسمك وعنوان المراسلة صممت من أجل الاستعمال المحلي فقط.

BLACK & DECKER HOME APPLIANCE 2 YEAR WARRANTY

Black & Decker provides a 2 Year Warranty for this product from the date of purchase against defects due to defective materials or workmanship. Motor/element burn-outs due to voltage fluctuations are not covered under warranty. If the product should become defective within the warranty period, Black & Decker will repair or (at Black & Decker's discretion) replace it free of charge.

The warranty provisions do not cover failure due to accident, misuse, abuse, negligence or non observation of local regulations on the part of the user. Equally, the warranty provisions do not apply where the appliance has been serviced by a person not authorised by Black & Decker or serviced with non-approved parts and this has contributed to the fault of the product. Superseded models without a replacement equivalent will either be repaired or (at Black & Decker's discretion) replaced with another product of similar retail value.

UPON PURCHASE

Fill in the Warranty Registration Card with the original Authorised Dealer's stamp (indicating date of purchase) and attach your purchase receipt to it. Retain in case of claims in the future.

MAKING A CLAIM

Take your defective product together with the Warranty Registration Card & purchase receipt to your local service Centre. You can either do this in person or send it freight prepaid. If mailing or shipping your appliance, ensure and remove all the water and pack it carefully in a sturdy carton with enough packing material to prevent damage. Include a note describing the problem to the service Centre and be sure to give your return address.

DESIGNED FOR DOMESTIC PURPOSES ONLY.

Names & Addresses of Black & Decker Houseware Service Concessionaires

Afghanistan - Ishan National Company, Opp. Ministry of Justice, Kabul. **Tel.:**+932-2101727 **Algeria** - SARL Outillage Corporation, 04 Route De Dely Brahimi Cheraga, Alger. **Tel.:**+21321-364363/508 **Fax:**+21321-369667. **Bahrain** - Fawaz Al Zayani, P.O.Box 26563, Adliya, Manama **Tel.:**+973-715252/712756 **Fax:**+973-713789. **Bangladesh** - Ultra Corporation, 8, Kushol Centre, Uttara, Dhaka, 1230. **Tel.:**+8802-8919272/9756 Ext.28 **Fax:**+8802-9887167. **Egypt** - Anasia Egypt for Trading S. A. E. P.O. Box: 2443, 110 Mostafa Refaat St, Sheraton, Heliopolis 11361, Cairo. **Tel.:**+202-2684159 **Fax:**+202-2684169. **Ethiopia** - Tewfik Sherif & Co. Ltd., P.O. Box 5583, Debre Zeit Road, Addis Ababa. **Tel.:**+2511-651700/601 **Fax:**+2511-650570. **India** - Gryphon Impex Pvt. Ltd., D-6/4, Okhla Industrial Area, Phase - I, New Delhi-110020. **Tel.:**+9111-26372602-4 **Fax:**+9111-26372601. **Iran** - **Tehran** - Service Centre of Iran, No 510, South Karger Ave, Below Pasteur Sq, Tehran. **Tel.:**+9821-6490608/0656/6407672 **Iran** - **Kish Island** - Cayhan Electric Co., No. 69, Paradise Shopping Centre, Kish Island. **Tel/Fax:**+98-76444-22894. **Jordan** - Bashiti Hardware, P.O. Box 1564, TLA Ali, Amman. **Tel.:**+9626-5350009/4770774 **Fax:**+9626-5350012/4789783. **Kenya** - Zyllog Enterprises, IPS Building, Kaunda Street, P.O.Box 40877, Nairobi. **Tel.:**+2542-338188/199 **Fax:**+2542-330642. **Kuwait** - Al Omar Technical Co., P.O. Box 4062, 13041 Safat, Kuwait. **Tel.:**+965-4848595/0039 **Fax:**+965-4845652. **Lebanon** - Est. F. A. Kettaneh SA, P.O.Box 110242, Dora Highway, Kettaneh Building, Beirut. **Tel.:**+9611-255860/6 **Fax:**+9611-255891. **Libya** - El Ghoul Brothers, P.O.Box 348, Islamic Call Bldg. Office 201-202, Benghazi. **Tel.:**+21861-9097681/4183 **Fax:**+21861-9094123. **Madagascar** - Group Tana Confort S. A. R. L., B. P. 1770, Antananarivo. **Tel.:**+26120-2264505 **Fax:**+26120-2264244. **Malta** - John G. Cassar Ltd., 36 Victory Str, Qormi QRM 06, Malta. **Tel.:**+35621-493251 **Fax:**+35621-483231. **Mauritius** - Happy World Marketing Ltd., Block 2, Industrial Estate, Coromandel, P.O. Box 429, Port Louis. **Tel.:**+230-2076700 **Fax:**+230-2337330/7400. **Nepal** - Universal Trading Centre, P.O. Box 1947, Tripureswor, Kathmandu. **Tel.:**+9771-262192/260587/785 **Fax:**+9771-261154. **Nigeria** - Amin Bros. Eng. Co. Ltd., 30A (Plot 1291), Akin Adesola Street, Victoria Island, Lagos. **Tel.:**+2341-3201778 **Fax:**+2341-2613667. **Oman** - OMASCO, P.O. Box 2734, Ruwi, Muscat. **Tel.:**+968-560232 **Fax** :+968-560255 **Pakistan** - **Lahore**- Electronics Inn, 212-G Raja Centre, Main Market, Gulberg, Lahore **Tel.:**+9242-5756750. **Philippines** - Modern House International Enterprises, 213 Rizal Ave. Extension, between 2nd and 3rd Ave. Extension, between 2nd and 3rd Ave. Kalookan City **Tel.:**+632-3664487 **Fax:**+632-3664489. **Qatar** - Al Mufthah Trading & Cont., P.O. Box 875, Doha. **Tel.:**+974-4650880/4448688 **Fax:**+974-4441415. **Saudi Arabia** - **Dammam** - Ebrahim Fawaz Al Zayani, P. O. Box 76026, Al Raka, Dammam. **Tel.:**+9663-8140914 **Fax:**+9663-8140824. **Jeddah** - Anasia, P.O. Box 50959, Jeddah - 21477. **Tel.:**+9662-6710014 **Fax:**+9662-6725929. **Jeddah** - EAC (Al Yousofi), P.O. Box 50959, Jeddah-21477. **Tel.:**+9662-6519912 **Fax:**+9662-6511153. **Madina** - Garziz Trad. for Bldg. Mat. & Decor., P.O. Box 30377, Jeddah-21477. **Tel.:**+9664-8261490/8227636 **Fax:**+9664-8265741. **Riyadh** - Anasia, P.O. Box 76026, Al Raka, Dammam. **Tel.:**+9662-6710014 **Fax:**+9662-6725929 **Yanbu** - Bin Afif, P. O. Box 530 Yanbu, Al Bahr. **Tel.:**+9664-3222626/8867 **Fax:**+9664-3222210. **Sri Lanka** - Delmege General Equip. Pvt. Ltd., 297, No. 428/1AT. B., Jaya Mawatha (Darley Road), Colombo-10. **Tel.:**+9411-2665914 **Fax:**+9401-2665915. **Sudan** - United Distribution Company, Sayed Addel Rehman Street, P. O. Box 325, Khartoum. **Tel.:**+24911-772612/777296 **Fax:**+24911-770919. **Tanzania** - General Motors Investment, 14 Vingunguti Nyerere Road, P. O. Box 16541, Dar Es Salaam. **Tel.:**+25522-2862661/5022 **Fax:**+25522-2862667/5412/3. **Tunisia** - **Sfax** - Techni-Sud, 68, Rue d'Algerie, Sfax. **Tel.:**+2164-226335. **UAE** - **Abu Dhabi** - Light House Electric., P.O.Box 120, Abu Dhabi. **Tel.:**+9712-6720667. **Dubai** - Black & Decker (O) A.G., P.O. Box 5420, Dubai. **Tel.:**+9714-7028234/233 **Fax:**+9714-2822765. **Dubai** - Ideal Machinery & Equipt. R. Workshop, P.O.Box 37116, Al Quoz, Dubai. **Tel.:**+9714-3474160 **Fax:**+9714-3474157. **Sharjah** - McCoy Middle East LLC, P.O. Box 20228, Sharjah. **Tel.:**+9716-5336321 **Fax:**+9716-5336320. **Uganda** - The Building Centre, Kitgum House, 52 Station Road, P.O. Box. 7436, Kampala. **Tel.:**+25641-234567 **Fax:**+25641-236413. **Yemen** - **Aden**- METCO Ltd. Mulla Dakka, Aden. **Tel.:**+9672-240950 **Fax:**+9672-240952. **Sana'a**- METCO Ltd., P.O.Box 12363, Hayel Street, Sana'a. **Tel.:**+9671-204201 **Fax:**+9671-204204. **Taiz** - METCO Ltd. Campa Area, Near Al Kair Mosque. **Tel.:**+9674-231610/232033 **Fax:**+9674-219869. **Zimbabwe** - J.D.Distributors, P.O. Box 226, 17 Bessemer Road, Graniteside, Harare. **Tel.:**+2634-753913/4/5/6/7 **Fax:**+2634-753918.



WARRANTY REGISTRATION CARD

YOUR NAME / الاسم _____

YOUR ADDRESS / العنوان _____

POSTCODE / الرمز البريدي _____

DATE OF PURCHASE / تاريخ الشراء _____

DEALER'S NAME & ADDRESS / اسم و عنوان البائع _____

PRODUCT MODEL NO. **FD1600**